



KENWOOD
Listen to the Future

European Tuning Conversions

Kenwood KTS-300MR and KTS-MP400MR

- With radio power on and in tuner mode.
- Press and hold preset buttons 1 and 5.
- While holding preset buttons 1 and 5, press and hold the reset button for 2-3 seconds.
- Release preset buttons 1 and 5 along with the reset button.
- The radio is now converted to European tuning.

Kenwood DIN style radios (KDCMP232 and KDC132)

- Turn radio on with SRC button.
- Press and hold SRC button for 3 seconds to turn radio fully off. (No Display)
- Hold preset buttons #1 and #5.
- While holding #1 and #5 down press SRC to turn radio on.
- Unit is now switched to/from European tuning.
- Note- The DIN radios will revert back to US tuning if power is removed from the unit.

KEC DVD-3 DVD Region switching

- Unplug IR eye from back of unit.
- Eject CD or DVD from player.
- Press "0422" on remote control, this brings current region code on TV screen.
- Press "0" then "enter" on remote.
- Press "play" on remote.
- Unit is now region-free for DVD playback.

TriStar Distributing- 1-800-621-2278 ask for tech support if you have questions or difficulty.